Philips
Micro Hi-Fi System

MP3/WMA-CD playback

Compact design

MCM118B

Compact audio system to match your lifestyle

Compact and stylish design packs a powerful punch. Combining superb performance and essential functionalities without compromising on aesthetics, just sit back and enjoy music the way you like it.

Enrich your sound experience
- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x15W RMS/2x30W music power

Wake up to CD or radio tunes
- Wake up and sleep timer functions
- Stereo tuning with digital readout

Fits any space, any lifestyle
- Compact design

PHILIPS
sense and simplicity

Micro Hi-Fi System
MP3/WMA-CD playback Compact design

MCM118B/12

Specifications

Sound
- Output Power: 2x15 watts RMS / 2x30 watts music power
- Sound Enhancement: Digital Sound Control, Dynamic Bass Boost
- Volume Control: Volume Control up/down

Loudspeakers
- Main Speaker: 3.5" woofer

Audio Playback
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

Tuner/Reception/Transmission
- Tuner Bands: FM Stereo, MW

Connectivity
- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, MW Antenna
- Aux in: Line-in, 3.5 mm

Convenience
- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: White
- Eco Power Standby: 1 watt

Accessories
- Remote control: 20-key with battery
- Included accessories: FM/MW Antenna
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages

Dimensions
- Set dimensions (W x H x D): 150 x 150 x 244 mm
- Main speaker dimensions (W x H x D): 150 x 150 x 200 mm
- Packaging dimensions (W x H x D): 535 x 200 x 302 mm
- Weight incl. Packaging: 5.5 kg

Highlights

Digital Sound Control
Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost
Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Issue date 2011-01-06
Version: 1.1.5
12 NC: 9073 100 13578
EAN: 87 10895 98614 4

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com